


## Transmission Control Module (TCM) I/O Signal

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

### 5. Transmission Control Module (TCM) I/O Signal

#### A: ELECTRICAL SPECIFICATION



AT-01451

**NOTE:**

The measurement should perform after warming up.

| Item                           | Connector No. | Terminal No. | Measuring conditions                            | Measured value  | Measure the resistance between terminal and chassis ground.                               | Remarks  |
|--------------------------------|---------------|--------------|---|---|---|--|
| P/L solenoid output            | B54           | 9            | Engine ON, "P" range, Accelerator OFF, Brake ON | Approx. 4.0 — 6.0 V   | 3 — 9 Ω (ATF temperature 20°C (68°F))   | Driving frequency 750 — 850 Hz   |
|                                |               |              | Manual mode 1st, Accelerator OFF, Brake ON      | Approx. 2.0 — 4.0 V   |   |  |
| PVIGN power supply             | B54           | 8            | Ignition switch ON                              | Power supply voltage  | —   |  |
|                                |               | 7            | Ignition switch ON                              | Power supply voltage  | —   |  |
| I/C oil pressure switch input  | B54           | 6            | —   | —   | —   | The condition of I/C oil pressure switch cannot be read by the tester. |
| Power GND                      | B54           | 5            | Always  | Approx. 0 V   | —   |  |
| CAN communication line (+)     | B54           | 4            | —   | —   | —   |  |
| CAN communication line (-)     | B54           | 3            | —   | —   | —   |  |
| ATF temperature sensor 1 input | B54           | 2            | Ignition switch ON                              | 2.5 — 2.9 V (ATF temperature 20°C (68°F))<br>0.8 — 1.0 V (ATF temperature 80°C (176°F)) | 4.0 — 5.0 kΩ (ATF temperature 20°C (68°F))<br>0.7 — 0.9 kΩ (ATF temperature 80°C (176°F)) |  |

## Transmission Control Module (TCM) I/O Signal

### AUTOMATIC TRANSMISSION (DIAGNOSTICS)

| Item                                     | Connector No. | Terminal No. | Measuring conditions                           | Measured value                             | Measure the resistance between terminal and chassis ground. | Remarks   |
|--|---------------|--------------|--|--|---|---|
| Battery power supply                     | B54           | 1            | Always   | Power supply voltage                       | —   |   |
| I/C solenoid output                      | B54           | 18           | While driving at 1st — 3rd of manual mode      | Approx. 5.5 — 7.5 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz  |
|  |               |              | While driving at 4th or 5th of manual mode     | Approx. 0 V                                |   |   |
| H&LR/C solenoid output                   | B54           | 17           | While driving at 2nd of manual mode            | Approx. 5.5 — 7.5 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz  |
|  |               |              | While driving at 3rd — 5th of manual mode      | Approx. 0 V                                |   |   |
| Control valve power supply output        | B54           | 16           | Ignition switch ON                             | Power supply voltage                       | —   |   |
|  |               |              | Ignition switch OFF                            | Approx. 0 V                                |   |   |
| LC/B solenoid output                     | B54           | 15           | While driving at 1st — 2nd of manual mode      | Power supply voltage                       | 5 — 17 Ω (ATF temperature 25°C (77°F))                      |   |
|  |               |              | While driving at 3rd — 5th of manual mode      | Approx. 0 V                                |   |   |
| Power GND                                | B54           | 14           | Always   | Approx. 0 V                                | —   |   |
| Analog GND (Sensor GND)                  | B54           | 13           | Always   | Approx. 0 V                                | —   |   |
| LC/B oil pressure switch input           | B54           | 12           | —  | —  | —   | The condition of LC/B oil pressure switch cannot be read by the tester. |
| ATF temperature sensor 2 input           | B54           | 11           | Ignition switch ON                             | 2.3 — 2.7 V (ATF temperature 20°C (68°F))  | 3.0 — 3.6 kΩ (ATF temperature 20°C (68°F))                  |   |
|  |               |              |  | 0.6 — 0.8 V (ATF temperature 80°C (176°F)) | 0.4 — 0.6 kΩ (ATF temperature 80°C (176°F))                 |   |
| PVIGN power supply relay output          | B54           | 10           | Ignition switch ON                             | 0 — 1.5 V                                  | —   |   |
| Fr/B solenoid output                     | B54           | 24           | While driving at other than 4th of manual mode | Approx. 4.5 — 6.5 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz  |
|  |               |              | While driving at 4th of manual mode            | Approx. 0 V                                |   |   |
| L/U solenoid output                      | B54           | 23           | When lock-up                                   | Approx. 3.5 — 5.5 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz  |
|  |               |              | When not lock-up                               | Approx. 0 V                                |   |   |
| D/C solenoid output                      | B54           | 22           | While driving at 1st or 5th of manual mode     | Approx. 5.5 — 7.5 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz  |
|  |               |              | While driving at 2nd — 4th of manual mode      | Approx. 0 V                                |   |   |
| D/C oil pressure switch input            | B54           | 21           | —  | —  | —   | The condition of D/C oil pressure switch cannot be read by the tester.  |
| Subaru Select Monitor communication line | B54           | 20           | —  | —  | —   |   |

## Transmission Control Module (TCM) I/O Signal

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

| Item                             | Connector No. | Terminal No. | Measuring conditions  | Measured value            | Measure the resistance between terminal and chassis ground. | Remarks |
|----------------------------------|---------------|--------------|---|---------------------------|---|---------|
| Control GND                      | B54           | 19           | Always  | Approx. 0 V               | —   |         |
| H&LR/C oil pressure switch input | B55           | 8            | While driving at 2nd of manual mode   | Power supply voltage      | —   |         |
|                                  |               |              | While driving at 3rd — 5th of manual mode   | Approx. 0 V               |   |         |
| Front vehicle speed sensor input | B55           | 7            | While driving at 2nd and 20 km/h (12 MPH) of manual mode                                | Approx. 140 — 170 rpm     | —   |         |
|                                  |               |              | While driving at 4th and 80 km/h (50 MPH) of manual mode                                | Approx. 560 — 680 rpm     |   |         |
| Lateral G sensor power supply    | B55           | 6            | Ignition switch ON  | 4.75 — 5.25 V             | —   |         |
| Lateral G sensor signal input    | B55           | 5            | Ignition switch ON, Engine ON, Flat value   | 2.0 — 3.0 V               | —   |         |
| Inhibitor switch 1 input         | B55           | 4            | Ignition switch ON, "P" range   | 4.0 — 5.0 V               | —   |         |
|                                  |               |              | Ignition switch ON, "N" range   | 1.5 V or less             |   |         |
| Inhibitor switch 2 input         | B55           | 3            | Ignition switch ON, "P" range   | 4.0 — 5.0 V               | —   |         |
|                                  |               |              | Ignition switch ON, "D" range   | 1.5 V or less             |   |         |
| Accessory power supply           | B55           | 2            | Accessory switch ON   | Power supply voltage      | —   |         |
|                                  |               |              | Accessory switch OFF  | Approx. 0 V               |   |         |
| Ignition power supply            | B55           | 1            | Ignition switch ON  | Power supply voltage      | —   |         |
|                                  |               |              | Ignition switch OFF   | Approx. 0 V               |   |         |
| Rear vehicle speed sensor input  | B55           | 18           | While driving at 2nd and 20 km/h (12 MPH) of manual mode                                | Approx. 190 — 230 rpm     | —   |         |
|                                  |               |              | While driving at 4th and 80 km/h (50 MPH) of manual mode                                | Approx. 760 — 920 rpm     |   |         |
| Fr/B oil pressure switch input   | B55           | 17           | Ignition switch ON, Engine ON, While driving at other than 4th                          | Approx. 0 V               | —   |         |
|                                  |               |              | Ignition switch ON, Engine ON, While driving at 4th                                     | Power supply voltage      |   |         |
| Turbine speed sensor 1 input     | B55           | 16           | 2nd of manual mode, Turbine speed sensor is 2,000 rpm (Read from Subaru Select Monitor) | Approx. 0 rpm             | —   |         |
|                                  |               |              | 4th of manual mode, Turbine speed sensor is 2,000 rpm (Read from Subaru Select Monitor) | Approx. 1,900 — 2,100 rpm |   |         |

## Transmission Control Module (TCM) I/O Signal

### AUTOMATIC TRANSMISSION (DIAGNOSTICS)

| Item  | Connector No. | Terminal No. | Measuring conditions  | Measured value                     | Measure the resistance between terminal and chassis ground. | Remarks                           |
|---|---------------|--------------|---|------------------------------------|---|-----------------------------------|
| Range lock solenoid output                    | B55           | 15           | Ignition switch ON, While stopping at "D" range   | About Power Supply Voltage - 1.2 V | 7 — 21 Ω  |                                   |
|   |               |              | Ignition switch ON, Vehicle speed at least 20 km/h (12 MPH)                             | Approx. 0 V                        |   |                                   |
| Inhibitor switch 3 input                      | B55           | 14           | Ignition switch ON, "R" range   | 4.0 — 5.0 V                        | —   |                                   |
|   |               |              | Ignition switch ON, "D" range   | 1.5 V or less                      |   |                                   |
| Inhibitor switch 4 input                      | B55           | 13           | Ignition switch ON, "P" range   | 4.0 — 5.0 V                        | —   |                                   |
|   |               |              | Ignition switch ON, "D" range   | 1.5 V or less                      |   |                                   |
| Control valve communication line              | B55           | 12           | —   | —                                  | —   |                                   |
| Back-up light relay output                    | B55           | 11           | Ignition switch ON, "R" range   | 1.5 V                              | Approx. 90 — 110 Ω (ATF temperature 25°C (77°F))            |                                   |
|   |               |              | Ignition switch ON, Other than "R" range  | Power supply voltage               |   |                                   |
| Ignition power supply                         | B55           | 10           | Ignition switch ON  | Power supply voltage               | —   |                                   |
|   |               |              | Ignition switch OFF   | Approx. 0 V                        |   |                                   |
| AWD solenoid output                           | B55           | 23           | Engine ON, "P" range or "N" range, Accelerator OFF                                      | Approx. 0 V                        | 3 — 9 Ω (ATF temperature 20°C (68°F))                       | Driving frequency 750 — 850 Hz    |
|   |               |              | Engine ON, "D" range, Accelerator OFF, Brake ON   | Approx. 2.0 — 3.0 V                |   |                                   |
| Turbine speed sensor 2 input                  | B55           | 22           | 2nd of manual mode, Turbine speed sensor is 2,000 rpm (Read from Subaru Select Monitor) | Approx. 1,300 — 1,500 rpm          | —   |                                   |
|   |               |              | 4th of manual mode, Turbine speed sensor is 2,000 rpm (Read from Subaru Select Monitor) | Approx. 1,900 — 2,100 rpm          |   |                                   |
| Control GND                                   | B55           | 21           | Always  | Approx. 0 V                        | —   |                                   |
| Inhibitor switch 3 open circuit monitor input | B55           | 20           | Ignition switch ON, "R" range   | 4.0 — 5.0 V                        | —   |                                   |
|   |               |              | Ignition switch ON, "D" range   | Less than 1.5 V                    |   |                                   |
| PN signal output                              | B55           | 19           | Ignition switch ON, Other than "P" range or "N" range                                   | Power supply voltage               | —   | ECM should be connected correctly |
|   |               |              | Ignition switch ON, "P" range or "N" range  | 0 — 1.0 V                          | —   |                                   |